



Notes:

- * These items are currently not in the Majestic Product Range
- ** This uses the TV Speakers to provide the centre Channel
- Inputs 1 to 4 Can be Audio or Audio Video devices (DVD players, Video, Sat TV etc)
- RM - Slave remote that only selects which of the 4 inputs are displayed on the TV
- RMM - Master remote to be used only in the Main Cabin Area.
- 12V DC - All items must have independant inline fuse**