



Notes:

\* These items are currently not in the Majestic Product Range

\*\* This uses the TV Speakers to provide the centre Channel

Inputs 1 to 4 Can be Audio or Audio Video devices (DVD players, Video, Sat TV etc)

RM - Slave remote that only selects which of the 4 inputs are displayed on the TV

RMM - Master remote to be used only in the Main Cabin Area.

**12V DC - All items must have independant inline fuse**